



ARIETE

NS2006Energy

The Ariete Energy Series high pressure homogeniser/pump features the latest in design concept, contributing to excellence in performance and reliability.

Liquid end

- High quality stainless steel and special high wear resistance materials for best mechanical and corrosion resistance performances
- 3A and electropolished versions available
- Ball (PVB) and poppet valves (PVP) interchangeable into the same block design for maximum product handling flexibility
- Aseptic version compression block available with sterile condensate packing flushing
- Various materials for pumping plungers

Homogenising valve

- One stage (standard on homogenizers) with hand wheel adjustment
- High efficiency design homogenizing valve, based on advanced fluid dynamics concepts
- Engineered for easy maintenance and cleaning
- Second stage optional

Power end

- Heavy duty and reliable power frame
- AC motor drive
- Splash type lubrication system
- "V" belts direct drive

Casing

- Polished stainless steel removable panels for easy access and maintenance
- Galvanized steel base frame on adjustable legs

Tools and spares parts

- Special tools and one set of emergency spare parts supplied with the machine
- O&M manual and Spare Parts list on CD-ROM

/25 +/- .787

/1.97

/25.8

/5.31

/3.74

/12 +/- .787

/19.7

/45.1 +/- .787

/25.8

/33.67

/7.87

/3.35

/20.9